

Installation of Speedy Dialer Pro

Do **NOT** connect your Speedy Dialer Pro hardware until the software has been installed.

Step 1: Install Cheetah Power Seller software CD in your desktop or laptop PC (Windows XP or Vista or 7 or 8).



The installation program should automatically start. If it does not, click **Start** in your PC's task bar, then click **Run**. Next, type **D:\AUTORUN.EXE** and press **<ENTER>**. (If the CD-Rom's drive letter is not **D**, substitute the appropriate drive letter).

This icon should appear on your PC desktop:



Step 2: Install the Speedy Dialer Pro hardware.

Follow steps
A, B, C, D.
(Step C has
2 options.)

A: USB Port

Plug the mini-USB jack into the back of the Speedy Dialer Pro and plug the standard USB jack into the USB port of your PC.

B: PC Audio

Plug the **black** jack into the jack on the back of the Speedy Dialer Pro. (Push it in firmly to seat it properly.) Then plug the **pink** jack (microphone) and the **green** jack (speaker) into your PC's sound card.



Your Speedy Dialer Pro should be located at least 12 inches away from any wireless devices.

Headset

C: 2.5mm Headset -(included) - plugs into front.


Firmly push the 2.5mm plug into the jack on front of Speedy Dialer Pro.

A loose connection can cause low audio and static to be heard on the headset. ...or if you supply your own...

C: Telephone Headset -plugs into back.

D. Telephone Line

Plug the phone cable from the wall into the RJ-11 jack on the back of the Speedy Dialer Pro. If your phone line is DSL, plug in a DSL filter.

After finishing the above 2 steps, you should see a green  status light in the front of your Speedy Dialer Pro, indicating that it is ready to use. If you do not see a green light, unplug the USB jack from your PC, wait about 5 seconds, then plug it in again. If you still do not see a green light, try another USB port.

See our Cheetah Support Page for the Software, Manual & Other Help

<http://www.HelpMeDial.com/cheetah>

Need Help? Call 866-439-6323 or 972-248-0341